


To partially fill and re-pressurise Rainwater Harvesting System



- i. Remove Sensor Switch (2) from between Filler (3) and Adaptor (1)
- ii. Connect Filler (3) directly to Adaptor (1)
- iii. Tank will fill from mains water. Run for 30 minutes.
- iv. Remove Filler (3) and re-insert Sensor Switch (2) into Adaptor (1)
- v. Re-insert Filler (3) into Sensor Switch (2)



- vi. To re-pressurise system, turn off Mains Switch (4), wait 5 seconds, and turn it back on again.